

## *The Probes*

### *Solutions for all your vehicle detection scenarios*



**P5050C Standard Probe Pkg.**

The **P5050 Standard** Probe:

- \* Non-discriminatory to inbound / outbound traffic
- \* Processors used: 111, 212, or 313 (12 VDC)
- \* Requires 22/4 shielded direct burial wire w/ drain
- \* Splice friendly up to 1 mile
- \* Commonly used when the wire and probe are installed separately



**P8000C Directional Probe Pkg.**

The **P8000 Directional** Probe:

- \* Discriminatory to inbound / outbound traffic
- \* Processors used: 212 only (12 VDC)
- \* Requires 22/4 shielded direct burial wire w/ drain
- \* Splice friendly up to 1 mile
- \* Most commonly used when there is a different action to be taken for inbound vs. outbound vehicles *or* when an action is to be taken for vehicle travelling only in a certain direction



**WP4C Complete Battery-Operated  
Wireless Probe Pkg.**

The **WP4 Battery Operated** Probe System:

- \* Non-discriminatory to inbound / outbound traffic
- \* Processors used: WP4 only (9 VDC)
- \* Requires any P500 series Probe
- \* **WP4** - Processor only    **WP4B** - Pkg. w/ no wireless included
- \* **WP4C** - Pkg. w/ Inovonics - 2000 ft.
- \* **WP4CLR** - Pkg. w/ Inovonics - 4000 ft.
- \* Most commonly used when trenching wire is impractical or undesirable



**P500B Basic Probe Pkg.**

The **P500 Basic** Probe:

- \* Non-discriminatory to inbound / outbound traffic
- \* Processors used: P500 only (12 VDC)
- \* Requires any P500 series probe
- \* Pre-attached 22/2 shielded direct burial wire w/ drain  
Part # = **P500 - 50 / 125 / 250 / 500 / 1000**
- \* Most commonly used for gate operation *or* when wire installation and probe installation coincide.

- \* All package systems are Plug & Play and contain all components needed \*
- \* All probes are designed for direct burial beside a 14 foot wide driveway \*
- \* All components of package systems may be purchased individually \*